

Smart Classroom Tech FAQ

- [Who do I contact for support?](#)
- [What equipment is included?](#)
- [What software is installed?](#)
- [What happens to data saved on a hard drive of the podium computer?](#)
- [Do I turn the computer on or off when finished?](#)
- [Can I play DVDs, Bluray, or VCR tapes?](#)
- [How do I connect my laptop, Ipad, or Tablet?](#)
- [Is there Internet or wireless access in my classroom?](#)
- [How do I turn the podium ON or OFF?](#)
- [How do I raise or lower the projector screen?](#)

Who do I contact if I need help with classroom technology/equipment?

In every technology-equipped classroom, you'll see an intercom panel on the top of the podium. Press the "AV HELP" or "TECH HELP" button, and someone from the [Classroom Technology Support team](#) will assist you. If not in the classroom, enter a support request at tech.appstate.edu and use Classroom Technology in the left column > classroom equipment problem.



Caption: What the tech help button on the podium looks like.

What equipment is included in a Smart Classroom?

Equipment varies, but there should be a data LCD projector, as well as:

- a podium
- document camera
- Dell or Mac computer
- Bluray/DVD/VCR combo
- Extron control systems
- possibly an Extron Touchpanel.

What software is installed on the fixed computer in a Smart Classroom?

Generally, Smart classrooms have Dell/Mac computers running the current Windows 10 Podium build or the latest Mac OS. The build includes Office 2019, SMART Notebook software, Google Chrome, other web browsers, and other university-licensed software.

What happens to the data if I save it on the hard drive of a computer located in the podium?

User profiles are wiped periodically from podium computers, so it is not recommended to save files on podium computers.

Do I turn the computer ON or OFF when I am finished?

Please leave the computers on as they perform automatic updates/maintenance functions on a nightly basis.

Can I play DVDs, Bluray, or VCR tapes?

Generally, the answer is yes. There should be a DVD/VCR/Bluray combo player located in the podium, however, we are no longer supporting/installing VHS/VCR units as they are no longer being manufactured. We suggest that you transition any VHS material to a DVD format. There is also the DVD drive of the computer. Use whichever you may have but make sure that you match the output by pressing the corresponding button to the control system in order to get sound (for example if you are using the PC - make sure you press the PC button located on the MLC226 Control panel).

How do I connect my laptop, Ipad, or Tablet?

The laptop connections are located at the top of the podium. We provide a VGA (analog 15pin) and an HDMI digital cable where equipped. Please locate the video output on your laptop/tablet/device and connect the corresponding cable. You may have to provide the appropriate adapter (if using a Mac or any device that uses any other connection other than VGA or HDMI). If you also want audio to be played from your laptop/tablet/device - then connect the 3.5 mm audio cable to your HEADPHONE jack on your laptop/tablet/device.

Remember to carefully connect/disconnect these cables.



Caption: what the Cable Cubby can look like

Is there Internet or wireless access in my Classroom?

If you have a University-owned laptop that has been registered, then you can use wireless. Otherwise, there are wired connections in each classroom for internet access.

How do I turn the Projector ON / OFF?

ON: locate the Extron controls on the top of the podium. You should see either a "PROJ ON" or "ON" button in the Display section in the upper left corner. Press that button once & the projector should power on.

OFF: locate the Extron controls on the top of the podium. You should see either a "PROJ OFF" or "OFF" button in the Display section in the upper left corner. Press that button once & the projector should power off.



Caption: On/Off button on the podium

How do I raise or lower the projector screen?

Manual: some rooms have not been outfitted with electric screens. To lower the manual projector screens - simply pull the string/handle down to the desired level and release. The screen should remain in that position. If not try again, as it could take more than one attempt.

Electric: locate the switch on the wall normally to the left (when facing the screen). Press the switch to the **DOWN** position to lower the screen/or to the **UP** position to raise the screen. **RAISE** the screen after each use.

***NOTE:** Many electric screens will **automatically LOWER** when the projector is **powered ON & raise** when the projector is **powered OFF**. There are also "SCREEN UP" & "SCREEN DOWN" buttons on the Extron MLC226 located on top of the podium.

Touch Panel: locate and press the 'SCREEN UP' & 'SCREEN DOWN' buttons on the Touch Panel interface.